


Amanero master JP1 1-2-3, JP2 off, JP3 1-2, JP4 off (J4/MCK_DAC out 24|25)
 Amanero slave JP1 1-2-3, JP2 off, JP3 1-2, JP4 off (J4/MCK_DAC in 24|25)
 Amanero slave JP1 2-3, JP2 on, JP3 1-2, JP4 off (J4/MCK_DAC in 45|49)
 XingU30 slave* JP1 1-2, JP2 on, JP3 2-3, JP4 off (J4/MCK_DAC in 45|49)
 XingU30 master JP1 1-2-3, JP2 off, JP3 2-3, JP4 off (J4/MCK_DAC out 24|25)



(*)- For slave mode XingU30
 red - remove
 green - connect